




Pivot Door
Sill Plate Mount
Installation:

Frame Assembly



RAM
WINDOWS



Pivot Door Frame Assembly Instructions




1. Attaching the Jambs to the Head



- A** Apply a strip of silicone between the Jamb and the Head
- B** Using (qty. 4) #6 x 1" screws, secure the jamb to the Head from the top. (Both Sides)

NOTE: Configuration of hole pattern may be slightly different that pictured.

2. Attaching the Jambs to the Sill




- A** Apply a strip of silicone between the Jamb and the Sill
- B** Using (qty. 6) #6 x 1" screws, secure the jamb to the Sill from the bottom. (Both Sides)

NOTE: Configuration of hole pattern may be slightly different that pictured.

Frame & Sill Mounting Parts




Sill Pivot Hinge



Concrete Screws



Concrete Drill





Brass Boss on bottom of sill

Sill Mount Plate Installation





1. Position Sill Mount Plate in the desired pivot location on the mounting surface
2. Use 1/4" Concrete drill provided to drill 2 holes in the outer locations on the plate
3. Use the concrete screws provided to anchor the Sill Mount Plate to the desired surface.
4. When installing the Pivot Door Frame, align the 2 extruded bosses on the Sill Pivot Hinge with the Mount Plate and snap into place. (use ample amount of silicone under sill prior to install)
5. Use frame screws to secure Pivot Door Frame into the rough opening.



Frame Assembly




1. Once the Sill Mount Plate has been secured, install the assembled pivot door frame by aligning the 2 brass boss pins extruding from the bottom of the frame sill and inserting them into the mounted Sill Plate.



NOTE: Apply ample amount of silicone under the sill as part of installation.

3. Frame Installation



A Secure the Door Frame with screws into the Rough Opening through each pre-drilled hole in each Jamb and the Head of the frame

C Frame MUST be square and plumb within rough opening. Use spacer around frame if needed

4. Panel Installation



1. Install panel by inserting the bottom pivot hinge on the panel with the pivot sill hinge located in the Sill.
2. Hold the panel perpendicular to the door frame and align the top of the panel hinge with the pin guide that is installed in the Head.
3. Use the supplied Allen tool by inserting the tool into the hole at the top of the panel and turning clockwise 16 turns. This will drive the pivot pin into the head and secure the panel.

